



CMS Bulletin 07-08  
Daylight Saving Time  
Attachment 1  
Samsung/Prostar Instructions

## Daylight Saving Time – Instructions to Program

### SAMSUNG/PROSTAR

#### TIME/DATE CHANGE

PRESS THE “TRSF” KEY

YOU WILL SEE: PROGRAMMING MODE, ENTER PGIM ID

DIAL “200”

YOU WILL SEE: ENABLE CUS. PROG, PASSCODE:

DIAL “12341”

PRESS “TRSF” KEY

PRESS THE “TRSF” KEY AGAIN

DIAL “505”

YOU WILL SEE: (E.G.OLD 30552197:0849)

TYPE IN THE NEW TIME AND DATE USING YOUR TELEPHONE:

W = DAY 0-6(0:SUN, 1:MON, 2:TUES, 3:WED, 4:THUR, 5:FRI, 6:SAT)

MM = MONTH 01-12

DD = DATE 01-31

YY = YEAR 00-99 (1990-2089)

HH = HOUR 00-23

MM = MINUTE 00-59

PRESS “TRSF” KEY TO STORE AND EXIT

HOURS NEED TO BE ENTERED IN MILITARY FORMAT (00-23 FOR THE HOURS AND 00-59 FOR THE MINUTES).

